

**SENESE**

**Cielo / Cielo Sans Deck Mounted Bridge Kitchen Faucet**

Installation Guideline

Senese Srl p.iva 01602790527  
Loc. Frassi 34, 53011 Castellina in Chianti  
[senese.com](http://senese.com)

## Cielo Bridge Gooseneck

### Deck-Mounted Two-Hole Bridge Gooseneck Faucet

#### Article

Polished Brass	LPP01LGCI ON
Polished Chrome	LPP01LGCI CR
Aged Brass	LPP01LGCI AB
Burnished Brass	LPP01LGCI BB
Satin Nickel	LPP01LGCI NS
Black Nickel	LPP01LGCI NN
Gold	LPP01LGCI OR

#### Cleaning

Wipe the surface with a soft cloth and lukewarm water and possibly with soap solution. Avoid alkaline, descaling or abrasive cleaners. Brass is a material that over time gets a beautiful patina but can be polished with brass polish. Aged and Burnished Brass also gets patina but should not be polished. The galvanized surfaces retain their lustre.

#### Decalcification

Aerators and shower handles should be regularly decalcified by placing them in a vinegar bath for a couple of hours. Should limescale stains occur, use eucalyptus oil and a soft cloth.

#### Lubrication

Lubricate only with silicone grease.



## Cielo Sans Bridge Gooseneck

### Deck-Mounted Two-hole Bridge Gooseneck Faucet

#### Article

Polished Brass LPP01LLCI ON

Polished Chrome LPP01LLCI CR

Aged Brass LPP01LLCI AB

Burnished Brass LPP01LLCI BB

Satin Nickel LPP01LLCI NS

Black Nickel LPP01LLCI NNO

Gold LPP01LLCI OR

#### Cleaning

Wipe the surface with a soft cloth and lukewarm water and possibly with soap solution. Avoid alkaline, descaling or abrasive cleaners. Brass is a material that over time gets a beautiful patina but can be polished with brass polish. Aged and Burnished Brass also gets patina but should not be polished. The galvanized surfaces retain their lustre.

#### Decalcification

Aerators and shower handles should be regularly decalcified by placing them in a vinegar bath for a couple of hours. Should limescale stains occur, use eucalyptus oil and a soft cloth.

#### Lubrication

Lubricate only with silicone grease.



## Installation Guide

### Before You Begin

- 1. Turn off the Water Supply**  
Ensure all water supply lines are completely shut off before beginning installation.
- 2. Flush Supply Lines**  
Run water through the supply lines to clear any debris or sediment. This prevents blockages or damage to internal components of the fixture.
- 3. Isolation Valves**  
We recommend installing isolation valves on the hot and cold inlet feeds for easier future maintenance.

### Installation Steps:

#### Position the Bridge Tap

- Insert the handle shanks through pre-drilled holes, 30mm diameter and 200mm centre-to-centre distance, in the mounting surface. Ensure the gaskets are in place beneath the escutcheons.

#### Secure the Components

- From underneath the mounting surface, attach the rubber washer, metal washer, and nut to the threaded handles. Tighten the nuts securely to prevent movement.

#### Connect the Water Supply

- Connect the 1/2" GAS/BSPP water supply lines to the fittings. Hot to the left and Cold to the right when facing the tap.

#### Flush and Test

- Remove the aerator from the spout using the plastic key. Turn on the water supply and open the handles to flush the lines.

### For assistance or technical questions

service@senese.com  
Tel: +39 0577 160 7485  
www.senese.com

