

**SENESE**

**Kappa Bold Kitchen Set**

Installation Guideline

## Kappa Bold Three Hole Kitchen Set

### Deck-Mounted Three-Hole Gooseneck Faucet with Three Spoke Lever Handles and Rinse

#### Article

Polished Brass	LTB01DMSK ON 1.110 Eur incl. VAT
Polished Chrome	LTB01DMSK CR 1.330 Eur incl. VAT
Aged Brass	LTB01DMSK AB 1.440 Eur incl. VAT
Burnished Brass	LTB01DMSK BB 1.440 Eur incl. VAT
Polished Nickel	LTB01DMSK NI 1.440 Eur incl. VAT
Satin Nickel	LTB01DMSK NS 1.670 Eur incl. VAT
Black Nickel	LTB01DMSK NNO 1.670 Eur incl. VAT
Gold	LTB01DMSK OR 1.995 Eur incl. VAT

#### Cleaning

Wipe the surface with a soft cloth and lukewarm water and possibly with soap solution. Avoid alkaline, acid-liming or abrasive cleaners. Brass is a material that over time gets a beautiful patina but can be polished with brass polish. Aged and Burnished Brass also gets patina but should not be polished. The galvanized surfaces retain their lustre.

#### Decalcification

Aerators and shower handles should be regularly decalcified by placing them in a vinegar bath for a couple of hours. Should limescale stains occur, use eucalyptus oil and a soft cloth.

#### Lubrication

Lubricate only with silicone grease.



## Installation Guide

### Before You Begin

- 1. Turn off the Water Supply**  
Ensure all water supply lines are completely shut off before beginning installation.
- 2. Flush Supply Lines**  
Run water through the supply lines to clear any debris or sediment. This prevents blockages or damage to internal components of the fixture.
- 3. Isolation Valves**  
We recommend installing isolation valves on the hot and cold inlet feeds for easier future maintenance.

### Installation Steps:

#### Position the Faucet

- Insert the spout shank and faucet bodies through the mounting surface. Ensure the gasket is beneath the escutcheon.
- Secure the spout by threading the washers and tightening the nut underneath.
- Required hole diameter: 30 mm. Recommended centre-to-centre distance: 100 mm.
- Maximum distance between components: 400 mm.

#### Secure the Faucet Base

- Tighten the mounting nuts onto the threaded shanks underneath the deck.
- Do not use grappling tools on the faucet, spout, or rinse, as this may cause damage to the finish.
- Important: Do not overtighten as this could cause damage to the faucet or deck.

#### Connect the Water Supply

- Attach the hot and cold-water supply hoses to the inlet connectors. Use PTFE (Teflon) tape on threaded connections where applicable to ensure a watertight seal.
- **Hot and cold levers connection:** the hot lever and the cold lever are connected to the rinse valve (diverter unit) using the provided flexible hoses.
- **Outlet connections:** from the rinse valve, connect the two outlet hoses to the spout and to the rinse (hand spray) as shown in the technical drawing.
- Double-check that each hose is routed without kinks, that all connections are fully seated, and that left and right connections match the product drawing before turning the water back on.

#### Flush the Faucet

- Open the faucet by turning the handles to the "on" position. Slowly turn on the water supply to allow water to flow through the faucet.
- Let the water run for a few minutes to clear out any remaining debris in the system.

#### Check for Leaks

- Inspect all connections for signs of leakage. If any leaks are found, ensure the fittings are properly sealed and re-tighten if necessary.
- Verify that there is no water ingress around the deck area that could cause future damage.

For assistance or technical questions: [service@senese.com](mailto:service@senese.com), Tel: +39 0577 160 7485, [www.senese.com](http://www.senese.com)

