

SENESE

Cielo / Cielo Sans Deck Mounted Gooseneck

Installation Guideline

Senese Srl p.iva 01602790527
Loc. Frassi 34, 53011 Castellina in Chianti
senese.com

Cielo Three Hole Gooseneck

Deck-Mounted Three-hole Gooseneck Faucet

Article

Polished Brass	LT01LGCI ON
Polished Chrome	LT01LGCI CR
Aged Brass	LT01LGCI AB
Burnished Brass	LT01LGCI BB
Polished Nickel	LT01LGCI NI
Satin Nickel	LT01LGCI NS
Black Nickel	LT01LGCI NNO
Gold	LT01LGCI OR

Cleaning

Wipe the surface with a soft cloth and lukewarm water and possibly with soap solution. Avoid alkaline, acid-liming or abrasive cleaners. Brass is a material that over time gets a beautiful patina but can be polished with brass polish. Aged and Burnished Brass also gets patina but should not be polished. The galvanized surfaces retain their lustre.

Decalcification

Aerators and shower handles should be regularly decalcified by placing them in a vinegar bath for a couple of hours. Should limescale stains occur, use eucalyptus oil and a soft cloth.

Lubrication

Lubricate only with silicone grease.



Cielo Sans Three Hole Gooseneck

Deck-Mounted Three-Hole Gooseneck Faucet

Article

Polished Brass	LT01LLCI ON
Polished Chrome	LT01LLCI CR
Aged Brass	LT01LLCI AB
Burnished Brass	LT01LLCI BB
Polished Nickel	LT01LLCI NI
Satin Nickel	LT01LLCI NS
Black Nickel	LT01LLCI NNO
Gold	LT01LLCI OR

Cleaning

Wipe the surface with a soft cloth and lukewarm water and possibly with soap solution. Avoid alkaline, acid-liming or abrasive cleaners. Brass is a material that over time gets a beautiful patina but can be polished with brass polish. Aged and Burnished Brass also gets patina but should not be polished. The galvanized surfaces retain their lustre.

Decalcification

Aerators and shower handles should be regularly decalcified by placing them in a vinegar bath for a couple of hours. Should limescale stains occur, use eucalyptus oil and a soft cloth.

Lubrication

Lubricate only with silicone grease.



Installation Guide

Before You Begin

- 1. Turn off the Water Supply**
Ensure all water supply lines are completely shut off before beginning installation.
- 2. Flush Supply Lines**
Run water through the supply lines to clear any debris or sediment. This prevents blockages or damage to internal components of the fixture.
- 3. Isolation Valves**
We recommend installing isolation valves on the hot and cold inlet feeds for easier future maintenance.

Installation Steps:

Positioning the Faucet

- Insert the spout shank through the central hole on the mounting surface. Ensure the gasket is beneath the escutcheon.
- Secure the spout by threading the washers and tightening the nut underneath.
- Required hole diameter: 30 mm.
- Recommended centre-to-centre distance: 100 mm.
- Maximum distance between components: 400 mm.

Installing the Handles


- Insert each handle body through its corresponding hole on the mounting surface.
- Secure using the rubber washer, metal washer, and nut beneath the surface.
- Ensure the handles are aligned correctly for smooth operation.

Connecting Water Supply

- Thread the tee fitting onto the spout shank and tighten securely. Use the provided rubber washer for a proper seal.
- Attach the flexible hoses to the tee and handles. Ensure the connections are tight but avoid over-tightening.


Testing

- Open the faucet and turn the water supply back on.
- Allow water to run through the faucet to flush out any remaining debris.
- Check for any leaks around the connections and handle assembly. Tighten any loose connections as needed.



1/2" NPT Connections supplied for Installations in the US and Canada

Flowchart
LT01LGCI / LT01LLCI



For assistance or technical questions

service@senese.com
Tel: +39 0577 160 7485
www.senese.com